

CAUTION- INSTALL AND USE THIS LUMINAIRE FOLLOWING YOUR LOCAL ELECTRICAL CODES AND REGULATIONS.

PREPARATION:

1). Read and understand instructions completely before installing this luminaire. If you are unfamiliar with electrical wiring have a qualified licensed electrician install this luminaire for you.

ELECTRICAL CONNECTIONS:

1). **WARNING-** Before starting the wire connections, disconnect the power by turning off the circuit breaker or removing the fuse at the fuse panel. Turning the power off using the light switch is not sufficient to prevent electrical shock.

2). This luminaire must be connected with supply wire rated at 90° C. Most dwellings built before 1985 have supply wire rated at 60° C; consult a qualified electrician before installing.

Step 1

Disassemble Luminaire Parts for Installation. Pull out the Luminaire Enclosure from Box.

Step 2

W: 8-3/4"
H: 7-1/4"
D: 5-1/8"

Make or prepare Wall cavity to Install the Luminaire Recessed Box, see Dimensions.

Step 3

Run Power Cord through the hole of Luminaire Recessed Box and install it into the Wall Cavity. Make sure Box is FLUSH to the Wall Surface.

Step 4

Connect the Wires from Luminaire to Input Wires from Power Conduit. **SEE WIRING DIAGRAM**

Step 5

Insert Luminaire into the Box, align the Clip and push until Luminaire is secure with Clamp Clips.

Step 6 Final Installation

Luminaire Box MUST be in the same level "Flush" with Wall Surface for Proper Luminaire Installation.

